

GOING FUTURE TODAY.



Universal broadband amplifiers

VARIO 561 F

VARIO 662 F

VARIO 683 F

VARIO 684 F



Betriebsanleitung

Before operating the device

NOTE: *Read this operating manual through carefully! It contains important information about installation, ambient conditions and maintenance of the device. Keep this operating manual for future use and for handover in the event of a change of owner or operator. A PDF version of this manual can be downloaded on the ASTRO website (there may be a more recent version).*

The ASTRO company confirms that the information in this manual was correct at the time of printing, but it reserves the right to make changes to the specifications, the operation of the device and the operating manual without prior notice.

Contents

Symbols and conventions used.....	page 04
Intended use.....	page 05
Intended audience for this manual.....	page 05
Device description.....	page 06
Important safety information.....	page 08
Information about supplying power remotely.....	page 12
Warranty conditions.....	page 15
Performance description.....	page 16
Disposal.....	page 17
Installation.....	page 17
Connection.....	page 19
Configuring the forward path.....	page 20
Configuring the return path.....	page 21
Measurements.....	page 22
Start-up.....	page 22
Troubleshooting.....	page 23
Maintenance and repair.....	page 23
Block diagram.....	page 24
Technical data.....	page 25
Drilling distances.....	page 31

Symbols and conventions used

Symbols used in this manual

Pictograms are visual symbols with specific meanings. You will encounter the following pictograms in this installation and operating manual:



Warning about situations in which electrical voltage and non-observance of the instructions in this manual pose a risk of fatal injuries.



Warning about various dangers to health, the environment and material.



Warning about thermal dangers due to hot surfaces.



Recycling symbol: indicates components or packaging materials which can be recycled (cardboard, inserts, plastic film and bags). Used batteries must be disposed of at approved recycling points. Batteries must be completely discharged before disposal.



This symbol indicates components which must not be disposed of with household rubbish.

Intended use

The VARIO 561 F, 662 F, 683 F and 684 F amplifiers are universal broadband amplifiers for bidirectional building distribution and broadband communication systems. It is exclusively designed for signal amplification in unidirectional and bidirectional distribution systems in single-family and multi-family dwellings.

Modification of the devices or use for any other purpose is not permitted and will immediately void any guarantee provided by the manufacturer.



Intended audience for this manual

Installation, configuration and start-up

ASTRO amplifiers are intended to be installed and put into operation by qualified experts who have training which enables them to perform the work required by EN 60728-11 and EN 62368-1. Unqualified persons are not permitted to install and operate the device.

Device description

The device packaging contains the following:

- VARIO 561 F, 662 F, 683 F and 684 F broadband amplifiers
- 0 dB pads for device configuration, inserted
- 2 zero cards of type VZ 1001, inserted
- Zero card VZ 1006, inserted
- 8 fuses
- Allen key 1.27 mm
- Operating manual




Fig. 1: VARIO 684 F amplifier

NOTE: The connection adapters for the input and output are not factory-installed. Please use the Allen key provided to install the inner conductor of the connector. Installation of the sockets is described in the "Installation" section. The connection adapters for the variant with order number 217 412 are available separately (see left):

PG 11 to F socket: Part number 790 511

PG 11 to IEC socket: Part number 790 512

PG 11 to 3.5/12" socket: Part number 790 510

- [1] Power indicator
- [2] Remote power supply socket
- [3] Earth terminal
- [4] Output 1
- [5] Output 2
- [6] Input
- [7] Screw mount for housing cover



- [1] Input equaliser
- [2] Input inverse equaliser
- [3] Input attenuation
- [4] Output test socket
- [5] Interstage equaliser
- [6] Interstage attenuation
- [7] Return path input attenuation
- [8] Optional diplex filter
- [9] Power supply unit cover
- [10] Output test socket
- [11] Power supply unit fuse
- [12] Optional distributor
- [13] Output 1 fuse
- [14] Test socket
- [15] Output 2 fuse
- [16] Input fuse
- [17] Optional return path amplifier
- [18] Optional diplex filter
- [19] Input test socket




Fig. 2: VARIO 561 F PG11 amplifier, interior



The VARIO 561 F, 662 F, 683 F and 684 F amplifiers have a CE marking. This confirms that the products comply with the relevant EC directives and adhere to the requirements specified therein.

Important safety information

To avoid any potential risks to the greatest extent possible, you must observe the following safety information:



ATTENTION: *Failure to observe this safety information may result in physical injury due to electrical and thermal dangers!*

Intended use

- Only use the device at approved operating sites and under approved ambient conditions (as described in the following), and only for the purpose described in the section "Proper use".

Before operating the device

NOTE: *Read this operating manual through carefully! It contains important information about installation, ambient conditions and maintenance of the device. Keep this operating manual for future use and for handover in the event of a change of owner or operator. A PDF version of this manual can be downloaded on the ASTRO website (there may be a more recent version).*

- Check the packaging and the device for transport damage immediately. Do not operate a device that has been damaged.
- Carrying the device by the power cable may damage the power cable or the strain relief and is therefore not permitted.

Installation and operation

- The device may only be installed and operated by qualified persons (in accordance with EN 62368-1) or by persons who have been instructed by qualified persons. Maintenance work may only be carried out by qualified service personnel.
- An installation site must be provided that prevents children from playing with the device and its connections.
- The electrical connection conditions must correspond to the specifications on the device type plate.



- To avoid damage due to overheating, the device may only be installed on vertical surfaces. The connection for the power supply unit must point to the right. The installation basis should be level and non-flammable. Operating position: Device vertical, with power supply output on the right.
- The permitted ambient temperatures specified in the technical data must be complied with. If the device overheats, the insulation used to insulate the mains voltage may be damaged.
- The device and its cable may only be operated away from radiant heat and other sources of heat.
- To avoid trapped heat, ensure there is good ventilation on all sides (minimum interval of 20 cm to other objects). Installing the device in recesses or covering the installation location, for example using curtains, is not permitted. Ventilation openings must not be covered.
- If the device is installed in a cabinet, ensure adequate air convection is possible to avoid exceeding the maximum permitted ambient temperature.
- No objects may be placed on the device.
- The subscriber network must be earthed in accordance with EN 60728-11 and must remain earthed even when the device is removed. In addition, the earth connection on the device can be used. Devices within hand's reach must also be integrated into the potential equalisation. Operating the device without an earth conductor, without earthing the device or without equipotential bonding of the device is not permitted.
- The device does not feature protection against water and may therefore only be operated and connected in dry rooms. The device must not be exposed to spraying water, dripping water, condensation or similar sources of moisture.
- The electrical system supplying current to the device, such as a building installation, must incorporate protective devices against excessive currents, earth faults and short-circuits in accordance with EN 62368-1.
- Caution! Hot surface: Housing components near the cooling fins at the rear or the cooling fins themselves may become very hot. Do not touch these parts.
- The power supply plug is used to disconnect the device from the mains voltage for servicing and in the event of danger and must therefore be accessible and in good working condition at all times. The device is operational when connected to the mains voltage.



- Adhere to all applicable national safety regulations and standards.
- Excess mechanical loads (e.g. falling, impacts, vibrations) may damage the insulation used to provide protection from the mains voltage.
- High excess currents (lightning strikes, surges in the power utility grid) may damage the insulation used to provide protection from the mains voltage.
- If there is no information about the intended use (e.g. operating site, ambient conditions), or the operating manual does not include the corresponding information, you must consult the manufacturer of this device to ensure that the device may be installed. If you do not receive the required information from the manufacturer, do not operate the device.
- In rooms in which the climatic conditions vary (e.g. due to sunlight), the device may only be operated if the permissible ambient temperature can be maintained.
- Disconnect devices with a damaged power cable from the mains (unplug the power supply plug).
- Always use the supplied power adapter (power supply unit) and connect it to a power point with a voltage within the range specified in the "Technical data" section. Failure to observe this warning may result in personal injury or equipment/property damage.
- Do not install the device in locations with excessive dust formation, as this may reduce the insulation from the mains voltage.

Electromagnetic compatibility (EMC)

In order to avoid malfunctions when operating radio and telecommunications equipment, as well as other operating units or broadcasting services, the following must be observed:

- Before installation, make certain that you have checked the device for mechanical damage. Do not use damaged or bent covers or housings.
- During operation, the device must always be covered by the components provided for this purpose. It is not permitted to operate the device when the cover is open.

- The braided shielding or the spring contacts must not be damaged or removed.

Maintenance

- The power indicator only shows whether the DC current, which supplies the device components, has been disconnected. However, if power indicators (on the power supply unit or the device) are not lit up, it is in no way an indication that the device is completely disconnected from the mains. There may still be voltage in the device that is dangerous to touch. Therefore, do not open the device.
- Read carefully: EN 60728-11 – Part 1, Safety requirements/No service work during electrical storms!
- Disconnect the mains plug before cleaning the device!

Repair

- Repairs may only be performed by the manufacturer. Improperly performed repairs may result in considerable dangers for the user.
- Do not operate devices with a damaged power cable. You must have the cable repaired by the manufacturer.
- If malfunctions occur, the device must be disconnected from the mains and authorised experts must be consulted. The device may need to be sent to the manufacturer.

General information

- Store or use the device in a safe location, well out of reach of small children. It may contain small parts that can be swallowed or inhaled. Dispose of any small parts that are not needed.
- Plastic bags may have been used for packaging the device. Keep these plastic bags away from babies and children to avoid any danger of suffocation. Plastic bags are not toys.
- Do not store the device near chemicals or in places in which any leakage of chemicals may occur. In particular, organic solvents or fluids may cause the housing and/or cables to melt or disintegrate, presenting a danger of fire or electric shock. They may also cause device malfunctions.
- Do not connect the supplied mains adapter to any other products.




Information about supplying power remotely

Remote power can be supplied in the following ways:

- Via strain relief to a PCB terminal block ($\leq 2.5 \text{ mm}^2$) in the power supply unit of the device, if a flat connector socket is not available
- Via a flat connector socket (6.3 x 0.8), if present
- Via a coaxial input or output

Overview of the remote power supply:



Remote feeding fuses depend on configuration of the device.

Wire routing (remote power supply) via strain relief for devices without a remote power supply socket

The external wires must be routed using round cable lines of the minimum quality specified below in order for the strain relief to be effective. After the cables have been connected, they must be adequately secured using the screw cap from the strain relief, so that an effective seal against environmental influences is also achieved.

When using F or K litz wires, make sure that no strands are split. Split strands can lead to short circuits in the device and thus to damage in the cable network.

Observe the installation conditions specified in EN60728 T11.

Minimum requirement for the cable types:

Round cable lines with a diameter of 5 - 8 mm, for example:

- H03VV-F 2x 0.75 mm², minimum diameter 5 mm
- H03VV-U 2x 0.75 mm², minimum diameter 5 mm
- H03VV-K 2x 0.75 mm², minimum diameter 5 mm

(F: flexible, U: rigid, K: finely stranded, fixed)

Remote power supply via the flat connector socket

The external wires must be routed using cable lines of the following minimum quality:

- H03V-F 0.75 mm²
- H03V-U 0.75 mm²
- H03V-K 0.75 mm².

Observe the operating conditions specified in EN60728 T11. Single conductors should be laid in such a way that they are protected and must not be subjected to tensile stresses during operation. The flat connector must be covered by external insulation which is fully intact.

Remote power supply via the coaxial sockets

Remote power supply via coaxial inputs or outputs is only permitted with appropriate connectors permanently mounted on the coaxial cables. The cable cross-sections and operating conditions specified in EN60728-11 must be observed.

Precautionary measures during connection and use of fuses

The device chassis conducts GND and ground potential.

Devices with a flat connector socket:

The supply voltage is supplied using either the coaxial inputs or outputs or the device's flat connector socket.

If power is supplied via the flat connector socket, the fuse in the power supply unit must be inserted. The fuses in the HF section of the device can be inserted according to the application.

If power is supplied via the coaxial connectors, the corresponding remote supply fuse in the power supply unit must be removed, as the remote supply voltage would otherwise be exposed at the open flat connector socket.

Devices with strain relief:

Power is supplied using either the coaxial inputs or outputs or the PCB terminal block built into the power supply unit.

If power is supplied via the PCB terminal block, which is built into the power supply unit, the fuse in the power supply unit must be inserted. The fuses in the HF section of the device can be inserted according to the application.

When the device is delivered, the strain relief is sealed with a sealing washer, which can be removed after the screw cap has been removed, but only for the purpose of feeding a cable through.

If power is supplied via the coaxial connectors, the corresponding remote power supply fuse in the power supply unit can remain inserted.

Installation instructions for remotely powered equipment

According to DIN EN 50083-1, only remote supply voltages up to 65 V AC are permissible. Voltages above 50 V AC are regarded as dangerous to touch. Therefore, they must not be accessible to laypersons and only accessible to trained electricians using tools. If there is a rupture at any point in the shielding (outer conductor) of the coaxial cable which is conducting current, the remote supply voltage may be present on the metal housing of the device through contact with the inner conductor and the circuit (danger of electrocution!). Therefore, the outer conductor connection of the cable that is supplying power must never be disconnected before its inner conductor connection is disconnected. (As a precaution, always turn off the remote supply voltage.) A safe outer conductor contact should be made with great care (observe the manufacturer's instructions).

The following protective measures must be taken:

- Equipotential bonding via the local PE connection*
An additional connection with an earth potential must be made using a cable with at least 4 mm² of copper at the PE terminal of the device. This connection can be made to a PE rail supplied by the customer or a local earth.

If this is not possible, one of the following safety measures should be provided:

- Equipotential bonding via the minimum cross section of the coaxial cable*
It must be permanently ensured that the remotely powered coaxial cable has a continuous outer conductor cross section of at least 4 mm² (from the supply point onwards).
Note: Braided cables do not usually have this cross-section!
- Equipotential bonding via several connected cables*
It must be ensured that at least one other connected coaxial cable is permanently connected to an earth potential along the length of its shield.
- Equipotential bonding in the area within hand's reach*
Equipotential bonding in the area within hand's reach of the device (i.e. a radius of 2.5 m) must be ensured. In order to achieve this, all conducting parts must be connected with the device with a copper conductor of at least 4 mm².

- Protection against contact via insulation in enclosed operating areas*

Remotely powered devices must be operated in enclosed operating areas. A warning sign must be provided, stating that supply voltage potential may be present on the device chassis in the event of a failure (e.g. a lightning bolt + "High voltage! In case of failure, do not touch!"). Cables leading directly to subscribers must be fitted with a galvanic outer conductor disconnecter.

- Limit the maximum remote supply voltage to 50 V AC*
The remote supply voltage may not exceed 50 V AC.

NOTE: *If several devices are supplied by separate cables, the polarity must not be reversed!*

Warranty conditions

The general terms and conditions of ASTRO Strobel GmbH apply. They can be found in the current catalogue or on the Internet under "www.astro-kom.de".

Performance description

The amplifiers of the VARIO series are locally or remotely powered broadband amplifiers. The division of the frequency ranges (upstream/downstream) is variable through the use of pluggable filters. You can activate the return path channel with optional diplex filters as well as with various active return path modules. (See "Technical data" section.) You can also activate the return path using the corresponding zero card included in the scope of delivery.

The inputs of VARIO amplifiers are equipped with a push-pull stage using GaAs technology. A GaAs line amplifier is also used in the output. This equipment ensures a very high dynamic range with low power consumption. The possibility of equalisation or interstage equalisation of incoming or outgoing cable attenuation allows for further improvement of the maximum output level and linearity.

The VARIO 561 F PG11, 662 F PG11, 681 F PG11, 682 F PG11 and 684 F PG11 amplifiers can be flexibly configured for future multimedia cable networks:

- 2 outputs (second output can be activated using various junction cards, see "Technical data" section)
- Adjustment of local level conditions using adjustable attenuators and equalisers (pads)
- Distribution of investment costs by upgrading with diplex filters and return path modules as required
- Return path can be activated with a plug-in module
- All return path amplifiers are uninterrupted
- Equaliser and attenuator in the optional return path module

In order to use the device properly, you must carefully read the following safety and operating instructions.



All of our packaging materials (cardboard boxes, inserts, plastic film and bags) are completely recyclable.

After use, this device must be disposed of in an orderly manner as electronic scrap, in accordance with the current disposal regulations of your district/country/state.

ASTRO Strobel is a member of the Elektro system solution for the disposal of packaging materials. Our contract number is 80395.

Installation

PREPARATION:

Before you can install the device, you must first drill three holes in a vertical installation surface and insert wall plugs into the holes. For the required borehole spacing and diameters, please refer to the “Drilling distances” section, page 31.

The following describes how to install the device:

TASK

1. Place the back of the device against the installation surface so that its oblong holes are exactly above the two wall plugs. The connection sockets of the device must point downwards.
2. Now screw the device in place with screws that match the size of the wall plug.

RESULT:

The device is now installed and you can begin the installation of the input and output sockets – if not pre-assembled ex works.

NOTE: *ASTRO cannot guarantee safety if the customer/user installs the sockets himself!*

If you nevertheless wish to assemble the sockets yourself, please observe the following assembly instructions.

First, screw the desired adapters (see page 3) or the cable fitting with PG11 thread onto the input and output connections of the amplifier.

Proceed as follows (see Fig. 3 below):




Fig. 3: Installing the input and output sockets

TASK

1. Using the supplied Allen wrench [1], loosen the grub screws [2] of the inner conductor terminal blocks [3] until the borehole for receiving the inner conductor in the inner conductor terminal block [4] is free.

IMPORTANT: In order to prevent the screw from falling out, do not unscrew the grub screw too far. If the grub screw is lost, proper operation of the amplifier is no longer possible.

2. Screw the previously selected connection adapter [4] or the cable fitting [7] (see left) to the housing connections [5] of the amplifier using a suitable wrench.

IMPORTANT: If you want to use a cable fitting with PG11 thread [7] or a connection adapter from a third party, shorten the inner conductor [6] to a length of 12 - 13 mm using pliers or another suitable tool.

A shorter contact pin cannot be used, as safe contact with the inner conductor terminal block [3] cannot be ensured. A contact pin that is too long would lead to safety problems and have a negative effect on the high-frequency characteristics of the amplifier.

3. Now use the Allen key [1] to tighten the grub screw [2] to ensure a safe contact between the inner conductor and the inner conductor connection block [3].

RESULT:

The device is now fitted with input and output sockets and can be connected.



Connection

PREPARATION:

To connect the amplifier to coaxial cables, you must first fit them with F connectors 75 Ohm. F connectors are available in various designs, so that direct connection of different cable diameters is possible.


The following describes how to connect the amplifier and coaxial cables:

TASK

1. Plug the F connectors into the corresponding sockets of the amplifier (input [6] and output 1 [4] or output 2 [5], see picture above left) and screw the outer ring of the F connector tight.
2. Make sure the coaxial cables are laid with a sufficient bending radius.
3. You can supply the device with a remote supply voltage via the input and output sockets. Alternatively, you can use the flat connector socket [2] to power the device locally.

RESULT:

The device is now ready for operation. The power indicator [1] (see picture bottom left) lights up.



Configuring the forward path

PREPARATION:

VARIO 561 F, 662 F, 683 F and 684 F equalisers have an input equaliser and pad in the forward path to equalise incoming cable attenuation [1], as well as an inverse input equaliser and pad to simulate cable attenuation [2] (see above left). Input attenuation is also adjustable with a pad [3]. Make the desired adjustments here by inserting the corresponding pads.

Between the amplifier stages (interstage), you can also set a pre-equalisation of the outgoing cable length by reinserting the jumper [5] accordingly (see picture bottom left). For attenuation you can also insert a pad here [6].


The amplifier's default configuration is for forward-only operation:

- The return path is deactivated (two zero cards of type VZ 1001 inserted, no modules for return path transmission inserted).
- The second output is deactivated (one zero card of type VZ 1006 inserted); to activate the second output, you must replace the zero card with a junction card of type VZ... or a distributor of type VZ... (see "Technical data" section).
- The jumpers for setting the equalisation and attenuation in the forward path and the return path input attenuation are set to 0 dB.

ATTENTION: *In cable networks that do not use a return path, the return path must remain deactivated.*

RESULT:

The device is now configured for the transmission of forward signals.



Configuring the return path

PREPARATION:

To transmit return signals, the amplifier must first be configured accordingly.


The following describes how to configure the amplifier for the transmission of return signals:

TASK

1. Replace each of the zero cards of type VZ 1001 in the input and output with a VD 33 or VD 65 diplex filter.
 2. To set up a passive return path, insert the two previously removed zero cards into both return path slots [14] (see centre left).
 3. To set up an active return path, insert one of the optionally available VR 411, VR 561, VR 661 or VR 761 return path modules into both return path slots.
 4. Adjust the input attenuation in the return path by inserting the corresponding pad [7] (see bottom left).
-

RESULT:

The device is now configured for the transmission of return signals.



Measurements

The VARIO 561 F, 662 F, 683 F and 684 F amplifiers have 4 test sockets. At the input, there is a bidirectional test socket [16] (see picture left) with 20 dB decoupling attenuation, which you can use to measure the input level for the forward path and the output level for the return path.

At the output, there are two directionally coupled test sockets [9] with 20 dB decoupling attenuation.

- Using the test socket [13] (5...862 MHz), you can measure incoming return signals from the distribution direction or incoming upstream signals before the return path amplifier. You can also perform an error analysis in the distribution direction (e.g. feed in a reference signal).
- You can use the test socket [10] (47...862 MHz with diplex filter VD 33, or 80...862 MHz with diplex filter VD 65) to measure outgoing signals in the distribution direction and to feed in return signals. (VARIO 684: only 80...1000 MHz, since the VD 33 cannot be used)


Using a further directionally coupled test socket [4], you can measure the return signal after the return path amplifier but before the setting elements of the return path module.



Start-up

When you have connected the mains voltage and the coaxial cables, the device is ready for operation and the levels can be set. To set the levels, you must make the following adjustments to the device:

- Adjust the input level as needed by inserting the pad for the attenuator [3] in the forward path (see picture left). Equalise the cable attenuation in the forward path as needed by inserting the pad for the equalisers [1] and [2] (see left). The equaliser [1] allows you to run a cable attenuation simulation.
- Equalise the cable attenuation in the return path as needed by inserting the pad for the equaliser [7] in the return path (see left).



Troubleshooting

If the device is not functioning correctly, perform the following checks:

- Check whether the coaxial cables are connected correctly and make sure there are no breaks or short circuits in the connectors.
- Check whether the output level on the device is within the permissible limits for the operating level.

If the problem cannot be resolved, please contact ASTRO customer service.


Maintenance and repair

ATTENTION: *It is essential that the following safety information be observed when performing maintenance and repair work. Failure to observe this safety information may result in physical injury due to electrical and thermal dangers!*



- The power indicator only shows whether the DC current, which supplies the device components, has been disconnected from the mains voltage. If the power indicator (for the power supply unit or the device) does not light up, it does not mean that the device has been fully disconnected from the mains voltage. There may still be voltage in the device that is dangerous to touch. Therefore, do not open the device.
- Read carefully: EN 60728 – Part 1 Safety requirements: No service work during thunderstorms.
- Disconnect the mains plug before cleaning the device!
- A defective device may only be repaired by the manufacturer to ensure that components with the original specification are used (e.g. power cable, fuse). Improperly performed repairs may result in considerable dangers for the user or installer. If malfunctions occur, the device must therefore be disconnected from the mains and authorised experts must be consulted. The device may need to be sent to the manufacturer.

Block diagram



Type		Vario 561 F	Vario 662 F
Order number		217 570	217 660
EAN-Code		4026187130398	4026187130459
Forward path			
Gain	[dB]	36 ± 0,8	36,5 ± 0,8
Frequency range	[MHz]	47 - 862	
Frequency flatness incl. temperature drift	[dB]	± 0,8	
Noise figure	[dB]	typ. 5 (± 0,5) / > 800 MHz: + 0,5 dB	
Attenuation (Input)	[dB]	0 - 20 (1 dB - steps)	
Attenuation (Interstage)	[dB]	0 - 7 (1 dB - steps)	
Equalizer (Input)	[dB]	0 - 20 (1 dB - steps)	
Equalizer (Interstage)	[dB]	0 - 10	
Base of equalizer	[MHz]	862	
Inverse Equalizer (Input)	[dB]	0 - 10 (0,5 dB - steps)	
Frequency base of inverse equalizer	[MHz]	47	
Tespoint (Input)	[dB]	return path 20 ± 1 / forward path 20 ± 2	
Tespoint (Output)	[dB]	20 ± 1 (directional coupling) 5 - 862 MHz	
Maximum output level			
42 Channels / linear	[dBμV]	110 (CTBA & CSOA ≥ 60 dB)	112 (CTBA & CSOA ≥ 60 dB)
42 Channels / 7 dB Slope	[dBμV]	112	114
Return path			
Frequency range	[MHz]	5 - 65 / 5 - 33	
Gain	[dB]	depends on return path module	
Diplex filter	[MHz]	5 - 33 / 47 - 862 (VD 33), 5 - 65 / 80 - 1000 (VD 65)	
Common data			
Power consumption with/without return path	[W]	14,5 / 12	15,5 / 13
Connectors	[Ω]	IEC-jack or PG 11	
Supply voltage	[V~/Hz]	24 - 65 / 50 resp. 60	
Testpoints		4	
Ambient temperature	[°C]	-15...+55	
Housing (W x H x D)	[mm]	204 x 73 x 150	
Weight	[kg]	2.7	
Return loss	[dB]	≥ 18 (> 14 MHz -1,5 dB/Octave) In-/Outputs & Testpoints	
EMC		accord. EN 50083-2	
Protection class		IP 54, categorie 2 accord. DIN EN 60529	

Power supply protection		T1,25A L 250V IEC60127 -3/4
Remote feeding fuse		T5A L 250V IEC60127 -2/3

Type	Vario 683 F	Vario 684 F
Order number	217 684	217 686
EAN-Code	4026187003050	4026187003074

Forward path			
Gain	[dB]	40 ± 0,8	40 ± 1 / > 862 MHz ± 1 dB
Frequency range	[MHz]	47 - 862	47 - 1006
Frequency flatness incl. temperature drift	[dB]	± 0,8	± 0,8 / > 862 MHz ± 1 dB
Noise figure	[dB]	typ. 5,5	typ. 5,5 / > 862 MHz: typ. 6
Attenuation (Input)	[dB]	0 - 20 (0,5 dB - steps)	
Attenuation (Interstage)	[dB]	0 - 7 (0,5 dB - steps)	
Equalizer (Input)	[dB]	0 - 20 (0,5 dB - steps)	
Equalizer (Interstage)	[dB]	0 - 10 (0,5 dB - steps)	
Base of equalizer	[MHz]	862	1006
Inverse Equalizer (Input)	[dB]	0 - 10 (0,5 dB - steps)	
Frequency base of inverse equalizer	[MHz]	47	
Tespoint (Input)	[dB]	return path 20 ± 1 / forward path 20 ± 2	
Tespoint (Output)	[dB]	20 ± 1 (directional coupling) 5 - 862 MHz	

Maximum output level			
42 Channels / linear	[dBμV]	113 (CTBA & CSOA ≥ 60 dB)	
42 Channels / 7 dB Slope	[dBμV]	115	

Return path			
Frequency range	[MHz]	5 - 65 / 5 - 33	
Gain	[dB]	depends on return path module	
Diplex filter	[MHz]	5 - 33 / 47 - 862 (VD 33), 5 - 65 / 80 - 1000 (VD 65)	

Common data			
Power consumption with/without return path	[W]	19,5 / 17	
Connectors	[Ω]	IEC-jack or PG 11	
Supply voltage	[V~/Hz]	24 - 65 / 50 resp. 60	
Testpoints		4	
Ambient temperature	[°C]	-15...+55	
Housing (W x H x D)	[mm]	204 x 73 x 150	
Weight	[kg]	2.7	
Return loss	[dB]	≥ 18 (> 14 MHz -1,5 dB/Octave) In-/Outputs & Testpoints	
EMC		accord. EN 50083-2	


Protection class		IP 54, categorie 2 accord. DIN EN 60529
Power supply protection		T1,25A L 250V IEC60127 -3/4
Remote feeding fuse		T5A L 250V IEC60127 -2/3

Zero cards, junction cards and diplex filters:

Typ	VZ 1001	VZ 1006	VZ 1007	VD 33	VD 65
Bestellnummer	216 278	416 001	416 002	216 653	216 652
Funktion	Nullkarte passiv-Rückweg	Nullkarte 1 Ausgang	Verteiler 2-fach	Diplexfilter	Diplexfilter
Frequenzbereich	-	-	5 - 1000 MHz	5 - 33 MHz / 47 - 862	5 - 65 MHz / 80 - 1000

Only the VD 65 diplex filter can be used with the VARIO 684.

Drilling distances





ASTRO Strobel Kommunikationssysteme GmbH

© 2021 ASTRO

Subject to change.

Change management and copyright:

This document contains information protected by copyright. It is prohibited to photocopy, duplicate, translate or store on data storage media this document, either partially or in full, without prior agreement of the ASTRO company.

These operating instructions have been written by:

ASTRO Strobel Kommunikationssysteme GmbH

Olefant 3, D-51427 Bergisch Gladbach (Bensberg) Germany

Phone: +49 2204/405-0, Fax: 02204/405-10

eMail: kontakt@astro-kom.de

Internet: www.astro-kom.de

All the information contained in this document has been checked in good faith. The ASTRO company cannot be held liable for any damage or injury arising in connection with the use of these operating instructions.